



Part #301-61000

Combination Pump Head Mount Bracket

1- The head mount kit should contain (2) 3/8-16 flat head bolts, (3) 3/8-16 low head bolts and (2) 3/8-16 hex head bolts w/ washers. Along with the head mount plate and stand off spacers.

2- Connect the standoff washers to the head mount plate by using the (2) 3/8-16 flat head bolts

3- Fasten the Head Mount Plate to the R/H Chevy cylinder head using te (3) 3/8-16 low head allen bolts.

4- connect the pump to the standoff spacers using the (2) 3/8-16 hex head bolts and washers. Be sure that the pump is mount so that the pressure out of the fuel pump is facing towards the carburetor.

5- once everthing has been connected you can begin to plumb the entire Pump system. Please be sure to use only the highest quality lines and fittings.



**Sweet Manufacturing
3421 S. Burdick St
Kalamazoo MI 49001
(800)441-8619
www.sweetmfg.biz**